

Jabra GN

www.jabra.com



Certified for

Skype for Business

Certified for

Microsoft Teams

EAC

Model: HSC016

P/N: **4999-823-109**

W08M Version: D

Jabra Evolve 20

Stereo MS

Country Of Origin: China

Corded Headset



EAN



5 706991 016970

UPC



7 06487 01496 6

S/N



00270637733



GN Audio A/S (GN Netcom A/S)
Lautrupbjerg 7, 2750 Ballerup, Denmark

TC




Jabra
GN

Jabra Evolve™ 20/20SE headset

Quick start guide



NOTE: USB-C connection is optimized for computers. USB-C connection with a mobile phone or tablet may give reduced performance.



Warning and Declarations

Corded and Wireless - Europe and Middle East

Please read through all applicable sections.

For your protection and comfort, GN Audio A/S ("GN") has implemented protective measures in this product designed to maintain safe volume levels and ensure that the product operates in compliance with government safety standards.

AUDIO PRODUCT WARNING!

PERMANENT HEARING LOSS MAY RESULT FROM LONG-TERM EXPOSURE TO SOUNDS AT HIGH VOLUMES. USE AS LOW A VOLUME AS POSSIBLE.

Avoid prolonged use of headsets at excessive sound pressure levels.

Please read the Safety Guidelines below prior to using this product.

You can reduce the risk of hearing damage by following these safety guidelines:

1. Prior to using this product follow these steps

- Before using the product, turn the volume control to its lowest level,
- Put the headset on, if applicable
- Slowly adjust the volume control to a comfortable level.

2. During the use of this product

- Keep the volume at the lowest level possible;
- If increased volume is necessary, adjust the volume control slowly;
- If you experience discomfort or ringing in your ears, immediately discontinue using the product.



With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

GENERAL SAFETY INFORMATION!

- If you have a pacemaker or other electrical medical devices, consult your physician before using this product.
- This package contains small parts that may be hazardous to children. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the product, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.

- Avoid exposing your product to rain or other liquids.
- Keep all products, cords, and cables away from operating machinery.
- Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircrafts.
- If the product overheats, has been dropped or damaged or has been dropped in a liquid, discontinue use.
- Dispose of the product according to local standards and regulations (see www.jabra.com/weee).



Remember: Always drive safely, avoid distractions and follow local laws!

The use of a speaker while operating a motor vehicle may be regulated by local laws. Using a headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check with your local authorities.

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery

- Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
- The battery can be charged and discharged hundreds of times, but will eventually wear out. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot or cold places will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A product with a hot or cold battery may not work temporarily, even when the battery is fully charged.

Battery warning!

- "Caution" – The battery used in this product may present a risk of fire or chemical burn if mistreated. Batteries may explode if damaged.
- Only recharge your battery with the provided approved chargers designated for this product.
- Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste or in a fire as they may explode.
- Unless otherwise specified in the user manual or quick start guide the battery in your product can not be removed or replaced by the user. Any attempt to do so is risky and may result in damage of the product.

For information on batteries please go to www.jabra.com/batteries.

CHARGER CARE: Please observe the following if the product is supplied with a charger

- Do not attempt to charge/power your product with anything other than the charger provided. The use of any other types may damage or destroy the product and could be dangerous. Use of other chargers may invalidate any approval or warranty. For availability of approved enhancements, please check with your dealer.
- Charge/power the product according to the instructions supplied with the product.

Important: Please refer to the user manual for a description of the charging status indicator lights. Some products cannot be used while charging.

Charger warning!

- Do not use a wall charger with more than 5V and 2A output.
- When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord. Never use a charger that is damaged.
- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock.

MAINTENANCE

- Unplug the product or charger before cleaning
- Clean the product by wiping with a dry or slightly damp cloth. The cord and charger may only be dry-dusted

DECLARATIONS

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Audio A/S is under license. Other trademarks and trade names are those of their respective owners. Wireless DECT standards vary depending on local legislation. Make sure that your product corresponds to the standard used in your country by ensuring that the product is purchased through a local source of distribution. For warranty information, please go to www.jabra.com.

EU Declaration

Hereby, GN Audio A/S declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU (Radio Equipment directive). For further information please consult the Declarations of Conformity section at www.jabra.com.